



OVERVIEW :

An equipment to test the quality of film / laminate in respect of its resistance to rupture due to sudden impact.

FEATURES :

- Foot-Operated Switch to Clamp / Un-Clamp the film sample.
- Umbrella switch to activate / de-activate the ElectroMagnet Coil.
- Foam Padding inside the Catching Pit (to protect damage to the falling dart).
Works on Pressure System (Compressed air is used to clamp the sample rather than the normal Vacuum system) and is easier to manage with negligible maintenance Uses standard compressed air
- supply available in any laboratory. No need for vacuum pumps, that are very noisy and require regular maintenance.

SPECIFICATION :

- Dart Set : Basic dart set with 200 – 300 grams weight. (5 gm increment).
- Standard Drop Height : 660 mm.
- Bounce Guard (to protect the Dart from bouncing off high-quality films).