



# VERTEX

## GANN MOISTURE METER-HYDROMETER



The HYDROMETTE COMPACT is an electrical resistance-type moisture meter, utilizing the relationship between moisture content and electrical resistance. The contact pins mounted on the top of the meter are used for making direct contact with the material. Various external electrodes are also available for specific applications. The HYDROMETTE COMPACT is especially useful for testing paperboard, corrugated stock, and paper tubes, Wood and gypsum. It is ideal for plant superintendents, inspectors, buyers, and salespeople.

### SPECIFICATION:

Three scales	2 : 5%-20% for paper.  3 : 5%-40%, for Wood.  B : 0.3 – 3.5 wt.% for Gypsum and Structural Moisture.
display	Bright, clear digital
Resolution	0.1%
Size (LXWXH)	20 X 3.5 X 3.5 cm.
Weight	130 gm
battery	9V

## FEATURES:

- Handy pocket sized moisture meter easy to carry anywhere.
- Calibration check with moisture calibrator.
- Integral contact pins mounted on top of meter provide 20mm penetration.
- Rugged construction ensures years of reliable use.
- Sturdy plastic carrying case.



<https://www.vertexmachines.com/>



+91 93234 05785



[info@vertexmachines.com](mailto:info@vertexmachines.com)

Actual product may differ in color and appearance due to constant development.