



VERTEX

CROSS HATCH ADHESION TESTER CROSS-CUT TESTER KIT



Multi-blades with 1mm/2mm/3mm Blades Cutter Spacing: 1 +0.01mm, 2+0.01mm, 3+0.01mm with Plastic Packing Box

- Precision Coating Adhesion Tester Quickly assess paint or coating adhesion on surfaces like metal, wood, or plastic—ideal for QC, R&D, and field use.
- Standardized Cut Patterns Includes interchangeable multi-blade cutters (1mm/2mm/3mm) to meet ASTM D3359, ISO 2409, BS 3900 & DIN standards.
- Durable & Ergonomic Build Solid stainless-steel cutter with an anti-slip handle ensures long life and comfort during repeated tests.
- Easy Result Evaluation Clear grid patterns allow for straightforward tape pull tests. Comes with a magnifier and brush for quick inspection & cleaning.
- Portable Complete Kit All tools packed in a compact carry case—perfect for lab or on-site testing. Includes cutter, brush, magnifier & instruction manual.



<https://www.vertexmachines.com/>



+91 93234 05785



info@vertexmachines.com

Actual product may differ in color and appearance due to constant development.